AAT FICT Traffic Plan

Version 28 (not to scale)

SITE SPEED LIMITS
Site Speed Limit 20
Sheds/Awning 5

LEGEND
Pedestrian walkway
Pedestrian crossing
Traffic directional arrows
Recommended Safety Phone Zones
Emergency Assembly Points
Sub Station
Light Tower
Vessel Working Exclusion Zone / Security Escort Only
Stevedore Traffic Flow
- Berth 1
- Berth 2
- Berth 3
Stop Sign
Give Way Sign

TRAFFIC FLOW Sunday 08-11-2026 Day

PORT DRIVE
AAT TRUCK MARSHALLING LANES
CAR PARK
KEEP CLEAR
MAINT. OFFICE
Training Rooms
OVERFLOW CREW ROOM
QUBE ADMIN OFFICE
UNX ADMIN OFFICE
QUBE AMENITIES
UNX AMENITIES
WORKSHOP
EMERGENCY ASSEMBLY & EVACUATION POINT A
AAT
MACHINERY PARKING
SECURITY
STOP
K BLOCK
L BLOCK
M BLOCK
D BLOCK
SEAFARERS
Flyover
STEVEDORE GEAR STORE
WASHBAY
W BLOCK
E BLOCK
SLIPWAY
Cross Over Point
CONTAINER TRUCK MARSHALLING
TRAILER PARK
(OLD D BLOCK ROWS 1-50)
CONTAINER TRUCK UNLOADING AREA
Forklift Loading High Traffic Area Proceed with Caution
TRAILER PARK 83-90
C BLOCK
G BLOCK
H BLOCK
STEVEDORE GEAR STORE
Forklifts Loading High Traffic Area Proceed with Caution
Road Closed (if required)
C34-47
Cross Over Point
REEFERS
J BLOCK
SHED 2
SHED 1
F2
F3
F1
B BLOCK
A BLOCK
Cross Over Point
Security Escort Only
BBC Newcastle
Direct to Truck
Start 0800/8 - ETD 1700/8
Cross Over Point
Security Escort Only
Pacific Titan
Discharge/Load: B F Blocks / Shed 1
Start 0600/7 - ETD 0800/10
A34-47
CAUTION
BRISBANE RIVER

Traffic flow can change on a daily basis based on operational requirements.