

AAT FICT Traffic Plan

Version 28 (not to scale)

SITE SPEED LIMITS
Site Speed Limit



Sheds/Awning



TRAFFIC FLOW Friday 5-6-2026 Update

PORT DRIVE


AAT Truck Marshalling Lanes Closed - Follow Signage for alternative marshalling lanes

LEGEND

- Pedestrian walkway
- Pedestrian crossing
- Traffic directional arrows

Emergency Assembly Points

- Sub Station
- Light Tower
- Vessel Working Exclusion Zone / Security Escort Only
- Stevedore Traffic Flow
 - Berth 1
 - Berth 2
 - Berth 3
- Stop Sign
- Give Way Sign



Opal Leader - Berth 4
Discharge: E Block
Start 0600/5 - ETD 1500/5

Security Escort Only
Nord Lotus
Discharge: Direct to Truck
Start 0800/3 - ETD 0900/6

Cross Over Point
Security Escort Only
Highland Chief
Discharge/Load: B Block
Start 2200/4 - ETD 2200/5

Cross Over Point
Security Escort Only
Viking Coral
Discharge: A C Blocks
Start 1300/5 - ETD 2200/5

Traffic flow can change on a daily basis based on operational requirements.